


Classroom TV Diagram

Classroom TV Operating Buttons



Special Tip: Connect a school VCR, DVD player or computer to the Channel One TV

To find out how, review the **Equipment Tips** chapter of this manual or click on the "Equipment Operation & Tips" tab at www.ChannelOneHelp.com.